

# Connectivity and housing selection tables

configure your system (continued)

RJ 45 PATCH AND USER CORDS					LCS <sup>3</sup>		
					Cat. 8 <b>N</b>	Cat. 6 <sub>A</sub>	Cat. 6
	LSZH	S/FTP	Impedance 100 Ω	0.5 m	0 337 01	-	-
				1 m	0 337 02	-	-
				2 m	0 337 03	-	-
				3 m	0 337 04	-	-
				5 m	0 337 05	-	-
				8 m	0 337 06	-	-
				10 m	0 337 07	-	-
				0.5 m	0 337 21	-	-
					0 337 08	-	-
				1 m	0 337 22	-	-
					0 337 09	-	-
				2 m	0 337 23	-	-
					0 337 10	-	-
				3 m	0 337 24	-	-
					0 337 11	-	-
				5 m	0 337 25	-	-
					0 337 12	-	-
8 m	0 337 26	-	-				
	0 337 13	-	-				
10 m	0 337 27	-	-				
	0 337 17	-	-				
	LSOH	S/FTP	Impedance 100 Ω	1 m	-	0 518 70	-
					-	0 518 66	-
				2 m	-	0 518 71	-
					-	0 518 67	-
				3 m	-	0 518 72	-
		-		0 518 68	-		
		5 m		-	0 518 73	-	
				-	0 518 69	-	
		F/UTP		Impedance 100 Ω	1 m	-	-
	-		-			0 518 50	
	2 m		-		-	0 518 55	
			-		-	0 518 51	
	3 m		-		-	0 518 56	
			-		-	0 518 52	
	5 m		-		-	0 518 57	
			-		-	0 518 53	
	U/UTP	Impedance 100 Ω	1 m	-	-	0 518 62	
-				-	0 518 58		
2 m			-	-	0 518 63		
			-	-	0 518 59		
3 m			-	-	0 518 64		
-	0 518 60	-					
5 m	-	-	0 518 65				
	-	-	0 518 61				